


- ① GUTTER AND END CAP.
- ② DOWNSPOUT.
- ③ WEATHERPROOF SUPPORT STRAP.
- ④ DIVERTER KIT AND HOSE.
- ⑤ RAIN BARREL.
- ⑥ WATER LINE.
- ⑦ SPIGOT TO DRAIN COLLECTED WATER.
- ⑧ 6"-12" ELEVATED FLAT SURFACE.
- ⑨ ROCK EROSION CONTROL AREA.
- ⑩ GUTTER EXTENSION.



NOTES:

- A. USE APPROVED BARREL. TRASH BINS AND OTHER SIMILAR ITEMS WILL NOT BE ACCEPTED.
- B. THE GUTTER AND DOWNSPOUT MUST BE SECURELY ATTACHED WITH GALVANIZED OR STAINLESS STEEL FASTENERS.
- C. POSITION DOWNSPOUT PROPERLY TO AVOID STANDING WATER.
- D. DRAIN OVERFLOW AWAY FROM HOME, OTHER STRUCTURES AND WALLS. DRAIN TOWARDS LANDSCAPE.
- E. ELEVATE BARREL WITH CMU BLOCK, PAVERS, STONE, CONCRETE, WOOD OR OTHER MATERIAL.
- F. DRAIN BARRELS AFTER EACH RAIN EVENT TO MAXIMIZE RAIN WATER USE FOR YARD.
- G. CONSIDER MATCHING COLORS OF COMPONENTS TO EXISTING SYSTEM AND/ OR ARCHITECTURE.
- H. USE ROCK, SPLASH PAD, PERFORATED PIPE OR DOWNSPOUT EXTENDER AT DISPERSION AREA.

RAIN BARREL

**Waterscape Rebate Program
County of San Diego**

WRP - 06